Electric Netting Repair

Fix your Kencove Electric Netting with ease using the **Electric Netting Repair Kit**.


1. Tie ends of broken twine into a secure knot.



2. After twine ends have been tied into a secure knot, move both ends to one side.



3. Place sleeve over both ends of the twine.



With a pair of pliers crimp one end of the sleeve over both pieces of twine.



5. Fold other end over the first crimp, overlapping both sections. Crimp again so the twine is secure.



6. With scissors, trim excess twine for a clean repair.





800-536-2683 www.kencove.com